



# Pickup Installation

The **Tunable** Steel Tongue Drum

1. Remove plug from Idiopan. (Push plug out from the inside)
2. Unscrew and remove nut and washer from jack.
3. Place pickup on the bottom of the inside of the drum, directly under the smallest tongue.
4. Feed jack through hole.
5. Apply nut and washer and use wrench to tighten snugly against Idiopan. **DO NOT OVER TIGHTEN!**
6. Plug in and play!

